



Installation of K1000 On/Off Repair Kit

- 1.) Assemble O-Ring Seal, with O-Ring facing point of Needle, mount Seal onto Needle shaft, followed by the Backup Ring (chamfer away from Seal).
- 2.) Lubricate Seal and O-Ring with H.P. Lubricant, screw Guide onto Valve Body.
- 3.) Push Kit Assembly, Using the Mandrel into Body until shoulder of Mandrel touches Guide, remove Mandrel and Guide.
- 4.) Mount Retainer into Valve Body, use H.P. Blue Lub, (Do not over tighten,) drop Seat into Body (Seat is reversible). Put O-Ring in, so that it is up against Seat. Only purpose of O-Ring is to keep Seat from falling out.

